

# **VariZoom VZ-RL100 OPERATING INSTRUCTIONS**

**\*\*\*PLEASE READ BEFORE USING\*\*\***

Thanks for purchasing our new deluxe variable-rocker LANC control, the VZ-RL100. Before you begin using your controller, here are a few **important guidelines to follow:**

**-ONLY PLUG INTO LANC COMPATIBLE CAMCORDERS**  
**-NEVER EXPOSE THE UNIT TO WATER OR LIQUIDS, AND NEVER EXPOSE IT TO EXCESSIVE HEAT, PRESSURE OR SHOCK – DOING SO MAY RESULT IN DAMAGE NOT COVERED BY THE FACTORY WARRANTY (2 YEARS)**  
**-DO NOT ATTEMPT TO OPEN THE UNIT. DOING SO MAY VOID YOUR FACTORY WARRANTY.**  
**-DO NOT SUBJECT THE VARIABLE ZOOM ROCKER OR THE LANC CABLE TO UNNECESSARY STRESS. ABUSE OF THE ZOOM ROCKER OR LANC CABLE MAY RESULT IN DAMAGE NOT COVERED BY YOUR WARRANTY!**

Your VZ-RL100 controller is equipped with the following features: **pressure-sensitive variable speed zoom control; record start/stop; LED indicator.**

## **HOW TO USE THE VZ-RL100**

1. Plug the controller into the LANC jack (“Control-L”) on your camcorder. If you are not sure about the location of the LANC jack, consult the camcorder owner’s manual.
2. You can attach the controller to your tripod handle, monopod, shoulder support, or stabilizer with the adjustable clamp (do not overtighten). The controller doesn’t require any external power or setup. Once connected, the VZ-RL100 is ready to perform.
3. The rocker switch at the bottom is for **zooming**. Since it is a variable rocker, the farther you press it right the faster it will zoom in (telephoto), and the farther you press it left the faster it will zoom out (wide). You should practice a bit before shooting so that you acquire a good sense of the rocker’s characteristics.
4. The small button marked with a red “R” is the **record start/stop** button.
5. Finally, the **LED indicator light** will turn red (or blink) to indicate a variety of camcorder functions such as record, tape end, low battery, etc. (the pattern will vary slightly between different camcorders, but will remain consistent when used with the same camcorder). You are ready to begin using the VZ-RL100. (*When not in use, disconnect the RL100*)

**Troubleshooting:** **1)** Zoom Creeping (unwanted zooming): Recalibrating the zoom center is easy. With the controller connected to your camera, loosen the brass set screw on the underside of the rocker with a 5/64” hex key (alan wrench), holding the rocker firmly in place. On the backside of the rocker is a hole with a slotted shaft, and this is where you adjust the zoom center with a flat screwdriver. Turn it slightly left and right and you’ll see the camera zoom in and out – find the centermost point between the zoom in/out start positions, then tighten the brass set screw (don’t overcrank it). **2)** Controller not responding: Unplug the unit and plug it back in after a few seconds.

512-219-7722 / [www.varizoom.com](http://www.varizoom.com)