

VariZoom Batteries	VariZoom Ni-MH Batteries			VariZoom Li-ion Batteries				
	SC-2112D	S-5056A S-5115A	S-5056A S-5115S	S-8056N	S-8080A S-8110A S-8160A	S-8080S S-8110S S-8160S	D-8081A D-8111A S-8161A	D-8081S D-8111S S-8161S
<b>Other Brand Chargers</b>								
<b>Sony NP-Style Chargers</b>	YES	NP-A	NP-S	NO	NO	NO	NO	NO
<b>Sony V-Mount Chargers</b>	NO	NO	YES	NO	NO	YES	NO	YES
<b>IDX NP-Style Chargers</b>	YES	NP-A	NP-S	NO	NO	NO	NO	NO
<b>IDX V-Mount Chargers</b>	NO	NO	NO	NO	NO	NO	NO	NO
<b>Anton Bauer Gold Mount Chargers</b>	NO	YES	NO	NO	NO	NO	NO	NO
<b>NOTES: "yes"= Can Charge "no"= Can't Charge "NP-A"= using the NP-A adaptor "NP-S"= using the NP-A adaptor</b>								

VariZoom Chargers	SC-302	D-3004A	D-3004S
	SC-304	SC-302A	SC-302S
<b>Other Brand Batteries</b>		SC-304A	SC-304S
		S-3802A	S-3802S
<b>Sony NP Ni-cd Batteries</b>	YES	NO	NO
<b>Sony V-Mount Ni-MH Batteries</b>	NP-S	NO	YES
<b>Sony V-Mount Li-ion Batteries</b>	NP-S	NO	YES
<b>IDX NP Ni-Cd Batteries</b>	YES	NO	NO
<b>IDX NP Ni-MH Batteries</b>	YES	NO	NO
<b>IDX NP Li-ion Batteries</b>	NO	NO	NO
<b>IDX V-Mount Ni-MH Batteries</b>	NO	NO	NO
<b>IDX V-Mount Li-ion Batteries</b>	NO	NO	NO
<b>Anton Bauer Gold-Mt Ni-Cd Batteries</b>	NP-A	YES	NO
<b>Anton Bauer Gold-Mt Ni-MH Batteries</b>	NP-A	YES	NO
<b>Anton Bauer Gold-Mt Li-ion Batteries</b>	NO	NO	NO