

VZ-TP760

Lightweight Travel Photo Tripod

VariZoom
www.varizoom.com

Thanks for your purchase of the TP760. This unit is rugged, light, and easy to use, but we have specific guidelines to ensure that you get your value out of the TP760. Please read the instructions before operating and note the following **warnings**:

- Whenever adjusting the ball head, grasp your camera firmly to prevent it from flopping over when the ball joint is loosened.
- Make sure the locking lever for the quick-release plate is securely fastened to prevent unwanted wiggle or accidental release of the plate from the head.
- Do not overload the tripod (7 lbs. max) and NEVER lean on it.
- We don't recommend transporting the tripod with the camera attached, as the camera is more likely to get damaged this way.

- 1) Attach the quick-release plate to your camera and tighten the thumbscrew securely.
- 2) Make sure the large ball-joint knob is tightened, then insert the plate (w/ camera attached) into the socket on the ball head and **tighten the locking lever securely** *.
- 3) Extend the legs to the desired height and secure the leg clamps so the legs don't slide.
- 4) The sliding latch at the top of each leg allows you to adjust the angle of the leg for a wider or narrower stance.
- 5) The telescoping center post allows you to fine tune the height of your camera. When the desired height is reached, tighten the thumbscrew to secure the center post position.



Should the leg clamps become loose over time, use the supplied socket wrench to tighten them.

