

The VZD100 collapsible dolly for use with the VZTC100A/C and VZT100A

WARNING: Do not leave the wheel brakes engaged when in storage or grooves may form in the wheel rubber.

Features:

- Fully collapsible wheel assembly.

Assembly:

The VZD100 is designed for use with the VZT100A, VZTC100A/C

The dolly can be collapsed for easy storage and transport. When setting up the dolly, you must unscrew the supplied locking screws completely, in order to move the legs round till they form a triangle. After setting the legs in the correct positions, you must take the locking screws and re-screw them into the legs.



In order to mount the tripod, you must remove the rubber feet till the tripods pointed inner feet are exposed. You will notice on the dolly a little spot which that pointed foot will sit within. Once you have them lined up and set, you must pull the large rubber section of the dolly leg upwards and over the lip, tightening it down.

Each of the wheels comes with a brake, in order to lock down movement and prevent the dolly from drifting. Just press down on the brake firmly with foot to lock.



The VZ-D100 tripod is covered by a one-year warranty (parts/labor). Please retain your receipt for warranty verification. All returns and repairs must be accompanied by a Return Merchandise Authorization number (RMA#). Contact us at 888-826-3399 / 512-219-7722 or at www.varizoom.com