

VariZoom

VZD100 (mkII) heavy-duty tripod dolly

Thanks for purchasing the latest version of our VZD100 dolly. New to this unit are improved wheels, quicker setup, more rugged construction, and compatibility with a range of upgrade accessories that make the dolly work with a wider range of tripods and even cranes.

Before removing the dolly from its bag, take note of the 2 leg-locking pins tethered to the upper plate. Also note that the lower plate has a grip cutout for easy handling. To deploy the legs into operating position, first pull out the 2 locking pins.



Carefully rotate each leg out until the leg pin holes align with the plate pin holes that are close to the VariZoom logo. Once aligned, insert the pins, slightly shifting the legs to allow insertion, if needed, and press the pins through until fully engaged.



Next, you'll need to roll the dolly into a position where you plan to mount the tripod.

We highly recommend locking the wheels before mounting the tripod to prevent the dolly from moving around.

The locking mechanism is a simple foot pedal that locks both the rolling and swiveling actions of the wheels. Simply press down on the lower part of the black pedal with your foot until it pops into position, and repeat on all 3 wheels. To unlock, press on the top part of the pedal until it snaps back into the free-rolling position.



Now you can mount your tripod. Install the claw foot and make sure it is centered, then secure it with the rubber strap. Make sure all 3 tripod feet are secure before releasing the wheel brakes.



1 year warranty for parts & labor

www.varizoom.com / 512-219-7722